



PART NUMBER

PFF5-1322

DESCRIPTION

GEARBOX MOUNTING BUSH INSERT

INSTALLATION GUIDE

Contents (parts per pack):

1 x PFF5-1322 Polyurethane Bushes

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Support the engine from underneath.
2. Locate the gearbox mount on the right hand side of the engine bay. This will involve removing the air intake system etc.
3. Remove the gearbox mount from the vehicle.
4. Clean any dirt from the voids in the mount and remove any flashing lines.
5. Insert the bush into the void at the top of the OE rubber mount.
6. Refit the mount to the car and tighten all hardware to the manufacturer's recommended settings.

