

POWERFLEX®

PART NUMBER

PFF26-122

DESCRIPTION

LOWER TORQUE MOUNT

INSTALLATION GUIDE

Contents (parts per pack):

1 x Pre-assembled Lower Engine Torque Mount

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with a workshop manual.

It is recommended that:

- All work is to be carried out by a licensed technician.
- All safety precautions are adhered to.
- Wheel alignment is to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Recommended Tools:

- Trolley Jack and Axle Stands
- 14 & 17mm Sockets / Spanners
- Ratchet or Impact Gun
- Torque Wrench

Fitting Instructions:

1. Raise the vehicle on either a lift or axle stands to gain access to the inspection hole and locate the Hyundai torque mount.

Note: We recommend using our PF26-160 Jack Pad Adaptor for the safer lifting of the Hyundai i30 N if using axle stands.

2. Undo the 17mm (B) and 14mm (A) bolts to remove the original torque mount.

3. Present the Powerflex Torque Mount to the vehicle, ensuring that all holes line up correctly with the gearbox mounting bracket and subframe.

4. Re-fit the 17mm & 14mm bolts, initially finger tightening and then tightening to Hyundai's recommended torque setting and lower the vehicle to finish.

