

# POWERFLEX®

## PART NUMBER

# PFF32-109G

## DESCRIPTION

## FRONT RADIUS ARM REAR BUSH ANTI PULL

## INSTALLATION GUIDE

### Product Description:

This part is designed to correct the misalignment of the front axle that causes the vehicle to pull to the left. The kit includes parts to correct both 0.5 and 1 degrees axle misalignment.

### Contents (parts per pack):

- 2x Polyurethane 32-109GA bush
- 2x Polyurethane 32-109GB bush
- 2x Polyurethane 32-109 bush
- 2 x M20 nylock nuts
- 2 x M20 steel washers
- 1 x PTFE / Silicone Assembly Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

### Fitting Instructions:

1. Remove the original bush from the car, clean any dirt and corrosion from the bore in the chassis, removing all sharp edges.
2. **If the front axle steering misalignment is unknown use the 0.5 degree offset setup.**  
(As shown in figure 1)
2. **If the 0.5 degree offset setup (As shown in figure 1) does not fully correct the pull on the vehicle to the left, then use the 1 degree offset setup.**  
(As shown in figure 2)
3. Apply some of the supplied PTFE/ Silicone grease to the bore and mounting faces of each bush and insert pin end of the arm into the bush.
4. Fit the original washer onto the end of the bush assembly, followed by the supplied M20 washer and M20 nylock nut.
5. Re-tighten all hardware to manufacturers recommended torque settings.

